

## LED Color Changing

### **For Glowballs, Glowclubs, Glow Staff**

1. Remove the old LED assembly by unscrewing the cap/switch and pulling out the LED/collar assembly and batteries.
2. Remove the new LED assembly from the shell using the same method as in step 1.
3. Place the new LED into your prop, add the batteries, and replace the cap/switch.
4. Place the old LED unit into the clear shell to keep the parts together and protect the LED.

### **For Husky Chuks and Clear Staff**

1. Remove the old LED assembly and replace it with the new one.

Enjoy your new colors! Be sure to follow the care & battery instructions that were shipped with your glow props.