

# Propellor Glowball Instructions

**Power** - These balls are powered by the speed of your poi swinging. They never need batteries!

**Installing the Propellor** - Your Propellor Glowballs come with propellers installed but they are breakable and can easily be replaced. Simply pry off the old propellor using a screwdriver or a knife blade and slide the new propellor onto the generator shaft, pressing down until it is firmly attached but spins freely.

**Tip:** To get more power out of your propellor, try increasing the curvature of the blades by GENTLY bending them to a steeper angle. Be careful! There is a fine line between adding more power and taking it away.

**Care** - Avoid hitting the nose of the propellor against hard surfaces as this may push the propellor too far down against the ball. To fix this, gently pull the propellor back away from the ball's surface using a knife or screwdriver.

**Cleaning** - For stains, use a small amount of vegetable oil and a dry cloth. General cleaning can be done with mild soap and water. Be careful to keep water out of the ball as this will interfere with the electronics.